




Ref No	Part No	Description
1	11400-24858	Gasket Set
1	11400-24880	Gasket Set
2	11141-24B03	• Gasket, Cylinder Head
3	11178-24B00	• O Ring, Head Cover
4	11241-24B01-H17	• Gasket, Cylinder
5	11482-24B11	• Gasket, Clutch Cover
5	11482-24B20	• Gasket, Clutch Cover
6	11483-24B01-H17	• Gasket, Generator Cover
7	11485-24B10	• Gasket, Gear Shift Cover
7	11485-24B20	• Gasket, Gear Shift Cover
8	14181-45C00	• Gasket, Exhaust Pipe
9	09168-06023	• Gasket (5.8x13x1.2)
10	09168-10031	• Gasket (10.2x20x2.3)
11	09280-07004	• O Ring (d:1.9,id:6.8)
12	09280-09005	• O Ring (d:1.9,id:8.6)
13	09280-10013	• O Ring (d:2.4,id:9.6)
14	09280-15007	• O Ring (d:2.4,id:15.8)
15	09280-17003	• O Ring (d:3.1,id:16.8)
16	09280-24010	• O Ring (d:2.4,id:23.7)
17	09280-33004	• O Ring (d:3.1,id:32.7)
18	09280-46002	• O Ring (d:2.4,id:45.7)
19	09280-60004	• O Ring (d:2.4,id:23.0)
20	09280-72001	• O Ring (d:2.4,id:73.0)




Ref No	Part No	Description
1	11100-24B10	Head Assy, Cylinder
2	09381-10003	• . Circlip
3	09206-08001	• . Pin
4	09206-11004	• . Pin
5	09103-06064	• . Bolt (6x60)
6	09103-06103	• . Bolt (6x70)
7	11115-44B70	Guide, Valve In (os:0.3)
8	11115-37470	Guide, Valve Ex (os:0.3)
9	11178-24B00	O Ring, Cylinder Head Cover
10	11141-24B03	Gasket, Cylinder Head
11	04211-13189	Pin
12	11145-37401	Cap, Head Seal
13	09108-08205	Stud Bolt (m12/8)
14	09108-08206	Stud Bolt
15	08316-10083	Nut
16	09103-06026	Bolt (6x40)
17	09103-06033	Bolt (6x125)
18	09103-06052	Bolt (6x115)
19	09103-06064	Bolt (6x60)
20	09103-06085	Bolt (6x130)
21	09103-06102	Bolt (6x55)
22	01550-06253	Bolt (green)
23	09159-09003	Nut
24	09159-09004	Nut
25	09168-10031	Gasket
26	09168-10031	Gasket
27	09168-06023	Gasket
28	09482-00334	Spark Plug (ngk,dpr8ea-9)
28	09482-00335	Spark Plug (denso,x24epr-u9)
28	09482-00354	Spark Plug (ngk,dpr7ea-9)
28	09482-00355	Spark Plug (denso,x22epr-u9)
29	11171-24B04	Cap, Head Cover Lh
30	11172-24B04	Cap, Head Cover Rh
31	11272-24B01	Cushion, Head Cover Cap Lh
32	11273-24B00	Cushion, Head Cover Cap
33	01550-06207	Bolt
34	01550-06653	Bolt
35	08313-20067	Nut
36	01500-06257	Bolt
37	09160-06134	Washer
38	11175-24B10	Cap, Inspection
39	09280-60004	O Ring (d:2.4,id:23.0)
40	01550-06203	Bolt
41	11186-24B02	Separator, Oil
42	09320-13015	Cushion
43	09241-30008	Plug, Cylinder Head
44	09301-06007	Bush
45	13101-14A10	Pipe, Intake
46	09280-46002	• . O Ring (d:2.4,id:45.7)
47	02112-16203	Screw
48	09402-58208	Clamp, Intake Pipe
49	09103-08170	Bolt (8x55)
50	08319-31088	Nut



Ref No	Part No	Description
1	11210-24B10-0F0	Cylinder
2	09108-09001	Stud Bolt (9x166)
3	09108-09002	Stud Bolt (9x178)
4	09108-09003	Stud Bolt (9x183)
5	09108-09004	Stud Bolt (9x203)
6	01421-06203	Stud Bolt (6x20) (green)
7	09145-06007	Nut
8	11241-24B01-H17	Gasket, Cylinder
9	04211-13189	Pin





Ref No	Part No	Description
1	11302-24851	Crankcase Set
2	09206-11007	• Pin
3	01547-06403	• Bolt
4	01547-06453	• Bolt
5	09103-06216	• Bolt
6	01547-06603	• Bolt
7	01547-06653	• Bolt
8	01547-06657	• Bolt
9	01547-06703	• Bolt
10	01547-06753	• Bolt
11	09168-06023	• Gasket (5.8x13x1.2)
12	09280-10013	• O Ring (d:2.4,id:9.6)
13	09493-36004	• Jet, Oil Gallery
14	09280-04004	• O Ring (d:1.2,id:4.0)
15	11971-25D00	Plug, Oil Filler
16	09280-17003	O Ring (d:3.1,id:16.8)
17	09247-12106	Plug, Oil Drain
18	09168-12002	Gasket
19	09247-14012	Plug, Oil Gallery
20	09168-14002	Gasket
21	09104-10034	Bolt (10x323)
22	09103-10087	Bolt (10x105)
23	09103-10053	Bolt (10x180)
24	11610-38400	Spacer
25	09159-10064	Nut
26	09159-10047	Nut
27	08322-01107	Washer
28	08322-01103	Washer
29	11384-24B01	Cover, Crankcase




Ref No	Part No	Description
1	12200-24B05	Crankshaft Assy
2	12161-24B01-0C0	. Rod, Connecting
3	12210-24B01-0A0	. Pin, Crank
4	09263-37004-0B0	. Bearing (37x47x25)
5	09160-37006	. Washer
6	12221-24B02	. Crankshaft, Rh
7	12261-24B02	. Crankshaft, Lh
8	09262-35038	Bearing, Rh (35x72x17)
9	09264-40002	Bearing, Lh (40x80x18)
10	09282-16002	Oil Seal, Rh (16x30x6)
11	12548-24B00	Retainer
12	01500-05083	Bolt
13	12661-24B00	Gear, Balancer Drive
14	04221-08149	Pin
15	12731-24B00	Sprocket, Cam Chain Drive
16	21111-24B10	Gear, Primary Drive (nt:37)
17	09140-20008	Nut
18	09164-20003	Lock Washer
19	12111-24B01-0F0	Piston
20	12140-14A32	Ring Set, Piston
21	12151-14A01	Pin, Piston
22	09381-23003	Circlip
23	12100-24B00-050	Piston Set (os:0.5)

Ref No	Part No	Description
1	12651-24B01	Balancer, Crank
2	12666-24B01	Gear, Balancer Driven
3	12669-24B01	Race, Inner
4	09420-04008	Key
5	09440-09031	Spring
6	09202-04017	Pin
7	09166-20010	Washer (20x54x2)
8	09181-20158	Washer
9	09262-20089	Bearing (20x47x14)
10	01500-10163	Bolt
11	08211-10285	Washer







Ref No	Part No	Description
1	12600-24B10	Limiter Assy, Starter Idle Gear
2	09181-10167	Washer
3	12612-24B03	Gear, Starter Idle No.2
4	09202-10011	Pin (1:30)
5	12600-24831	Clutch Set, Starter
6	09263-31009	• . Bearing (31x39x17.8)
7	07130-08163	Bolt
8	12656-24B02	Flywheel
9	12664-24B01	Nut
10	09164-35002	Washer




Ref No	Part No	Description
1	12711-24B11	Cam Shaft
2	12741-24B00	Sprocket (nt:38)
3	09261-05009	Pin
4	12747-44000	Washer
5	09111-06053	Bolt (6x16)
6	09390-25003	C Ring
7	12840-24B10	Arm, Valve Rocker Intake
8	12842-32411	• . Screw
9	12843-32400	• . Nut
10	12850-24B10	Arm, Valve Rocker Exhaust
11	12842-32411	• . Screw
12	12843-32400	• . Nut
13	12861-12D00	Shaft, Rocker Arm Intake
14	12871-14A00	Shaft, Rocker Arm Exhaust
15	09280-09005	O Ring (d:1.9,id:8.6)
16	09164-12018	Washer
17	09248-14005	Plug, Rocker Arm Shaft
18	09168-14002	Gasket
19	02162-06303	Bolt, Shaft Exhaust
20	09168-06023	Gasket
21	12941-24B01	Shaft, Decomp
22	09282-10012	Oil Seal (10x20x6)
23	12942-24B00	Lever, Decomp Shaft
24	09448-17020	Spring
25	08316-10083	Nut (green)
26	09103-06090	Bolt (6x16)
27	09168-06023	Gasket
28	12944-24B00	Holder, Decomp Cable
29	02122-05103	Screw
30	12911-24B01	Valve, Intake
31	12912-24B01	Valve, Exhaust
32	12920-37402	Spring Set, Valve
33	12931-45000	Retainer, Spring
34	12932-82000	Cotter, Valve
35	12933-37400	Seat, Spring
36	09289-07002	Oil Seal (7x14.4x9)




Ref No	Part No	Description
1	12760-24B00	Chain, Cam Shaft Drive
2	12771-24B01	Guide, Cam Chain
3	12811-24B00	Tensioner, Cam Chain
4	12812-24B00	Bolt
5	09168-08016	Washer
6	12830-24B01	Adjuster Assy, Tensioner
7	09108-08194	Bolt (8x18)
8	09119-06069	Bolt (6x12)
9	08331-31086	Circlip




Ref No	Part No	Description
1	13200-24C90	Carburetor Assy
1	13200-24CA0	Carburetor Assy
2	13500-24B40	• Diaphragm Assy
3	13389-37400	• Plate
4	02112-03063	• Screw
5	08321-21033	• Lock Washer
6	13387-44030	• Ring
7	13394-31210	• E Ring
8	13382-44030	• Washer
9	13388-44030	• Spring
10	13383-24C40	• Needle, Jet (5c39)
11	09494-00861	• Jet, Needle (x-7m)
12	13503-24B00	• Spring
13	13502-37400	• Cover
14	09404-06433	• Clamp
15	02112-05103	• Screw
16	09491-29013	• Jet, Main (145)
17	13382-03110	• Washer
18	09492-52010	• Jet, Pilot (52.5)
19	13370-24C80	• Valve Assy, Needle
20	13376-19F00	• Filter
21	13374-35C00	• O Ring
22	13373-39110	• Plate
23	02112-04063	• Screw
24	13250-37400	• Float
25	13254-92311	• Pin, Float
26	13251-38300	• Gasket
27	02112-35163	• Screw
28	13247-13A00	• Screw, Drain
29	13411-24C00	• Plunger Assy
30	13484-38A10	• Cover
31	13481-38B40	• Spring
32	13480-05A10	• Diaphragm Assy
33	02112-04103	• Screw
34	13267-25D00	• Adjuster
35	13271-93011	• Spring
36	13621-24B01	• Bracket
37	02112-05103	• Screw
38	13318-24C00	• Hose Assy
39	09352-50823-600	• Hose (5x8.2x600)
40	09491-46005	• Jet, Pilot Air No.2 (230)
41	13269-37400	• Screw, Pilot (1,1/8)
42	13268-47070	• Spring
43	13291-29900	• Washer
44	13295-29900	• O Ring
45	13281-05A00	• Plug
46	09491-45002	• Jet, Pilot Air (45)




Ref No	Part No	Description
1	13700-24B05	Cleaner Assy, Air
2	13780-24B01	• . Filter
3	02112-05107	• . Screw
4	08321-01057	• . Lock Washer
5	13740-24B01	• . Cap
6	02142-05123	• . Screw
7	13881-24B01	• . Tube, Outlet
8	09402-70203	• . Clamp
9	09402-64203	• . Clamp
10	13891-24B00	• . Tube, Inlet
11	09352-11153-600	• . Tube, Breather (l:600)
12	09401-14301	• . Clip
13	13870-11458	• . Tube, Drain
14	09401-13409	• . Clip
15	13859-41B10	• . Plug
16	09401-14301	• . Clip
17	09116-06006	Bolt (6x16)
18	01550-06123	Bolt




Ref No	Part No	Description
1	14150-24B01	Pipe, Exhaust
2	14181-45C00	Gasket, Exhaust Pipe
3	14182-38A02	Clamp, Exhaust Pipe
4	09104-08026	Bolt (8x35)
5	14771-46E00	Connector, Muffler
6	14459-14A10	Clamp, Muffler Connector
7	01550-08403	Bolt
8	14310-24B44-H01	Muffler
9	14780-24B01	Cover, Exhaust Pipe
10	14789-24B12	Gasket
11	02112-06103	Screw
12	14790-24B00	Cover, Muffler
13	14785-24B00	Clamp
14	01550-06203	Bolt
16	09103-08505	Bolt (8x20)
17	09180-08189	Spacer (8.5x12x11)
18	09320-12041	Cushion
19	09160-08134	Washer (8.5x26x1.6)
20	08319-31088	Nut




Ref No	Part No	Description
1	16400-24B00	Pump, Engine Oil
2	16331-24B00	Gear, Driven (nt:35)
3	09261-04009	Pin
4	09181-10158	Washer
5	08331-31106	Circlip
6	02112-06253	Screw
7	16520-24B00	Strainer, Engine Oil
8	01580-05123	Bolt
9	16510-37450	Filter, Engine Oil
10	09280-15007	O Ring (d:2.4,id:15.8)
11	16512-24B00	Cap, Oil Filter
12	09280-72001	O Ring (d:2.4,id:73.0)
13	09440-21006	Spring
14	09106-06090	Bolt



Ref No	Part No	Description
1	21200-24B12	Gear, Primary Driven (nt:67)
2	08211-22443	Washer
3	09180-22023	Spacer (22x28x32.5)
4	21411-37401	Hub, Sleeve
5	09140-22009	Nut
6	09167-22005	Lock Washer
7	08211-22403	Washer
8	21441-37400	Plate, Drive (id:116)
9	21442-37401	Plate, Drive (id:120)
10	21471-37400	Seat, Wave Washer (t:1.4)
11	09164-00004	Wave Washer
12	21451-14A00	Plate, Driven
13	21462-37400	Disk, Pressure
14	21465-37400	Plate, Release
15	09440-20016	Spring
16	01550-0620A	Bolt
17	16321-24B00	Gear, Oil Pump Drive (nt:30)
18	09261-06002	Pin (6x6)
19	23121-24B02	Piece, Clutch Push
20	09262-12001	Bearing (12x28x8)
21	09280-09005	O Ring (d:1.9,id:8.6)
22	23111-24B00-445	Rod, Clutch Push
22	23111-24B00-455	Rod, Clutch Push
22	23111-24B00-465	Rod, Clutch Push
23	23263-24B01	Cam, Release
24	23270-24B03	Arm, Release
25	09448-13010	Spring
26	09181-10111	Washer (10x14x1.0)
27	09280-07004	O Ring (d:1.9,id:6.8)
28	04111-20208	Cotter Pin




Ref No	Part No	Description
1	24121-24B12	Countershaft (nt:15)
2	24221-24B21	Gear, 2nd Drive (nt:19)
3	24231-24B30	Gear, 3rd Driven (nt:21)
4	08211-25351	Washer
5	09380-25003	Circlip
6	24241-24B20	Gear, 4th Drive (nt:23)
7	24252-19F00	Bush
8	09167-25012	Washer (25.1x31x1.0)
9	24251-24B13	Gear, 5th Drive (nt:26)
10	09380-25010	Circlip
11	09262-22028	Bearing, Rh (22x56x16)
12	09262-17027	Bearing, Lh (17x40x12)
13	24741-24B00	Holder, Bearing
14	02112-0612A	Bolt
15	24130-24B12	Drive Shaft
16	24311-24B11	Gear, 1st Driven (nt:35)
17	09300-20032	Bush
18	09181-20195	Washer (20x30x1.0)
19	24321-24B20	Gear, 2nd Driven (nt:30)
20	09300-25020	Bush
21	08211-25351	Washer
22	09169-25001	Washer (25.1x37x2.5)
23	09167-25013	Washer (25.1x41x1.5)
24	09167-25016	Washer (25.5x35x1.0)
25	09380-25003	Circlip
26	24331-24B20	Gear, 3rd Driven (nt:24)
27	24332-24510	Bush
28	24341-24B20	Gear, 4th Driven (nt:22)
29	24351-24B13	Gear, 5th Driven (nt:23)
30	09262-20106	Bearing, Rh (20x42x12)
31	09262-25125	Bearing, Lh (25x62x17)
32	09283-36003	Oil Seal, Lh (36x50x6.0)
33	24751-24B00	Holder, Oil Seal
34	01547-0612A	Bolt
35	27510-24B01	Pulley, Front
36	27531-24B00	Spacer
37	09280-24010	O Ring (d:2.5,id:23.8)
38	09159-20004	Nut
39	09167-25019	Lock Washer
40	27611-24B00-133	Belt, Drive
41	26131-24B00	Gear, Driven (nt:8)
42	26481-24B01	Sleeve
43	09280-10001	O Ring (d:1.3,id:9.6)
44	09135-06013	Bolt (6x10)
45	09168-06004	Washer (6.2x11x1.2)





Ref No	Part No	Description
1	25211-24B10	Fork, Gear Shifting No.1
2	25221-24B10	Fork, Gear Shifting No.2
3	25231-24B10	Fork, Gear Shifting No.3
4	25411-24B00	Shaft, Gear Shifting Fork
5	25310-24B11	Cam, Gear Shifting
6	04221-04089	• Pin
7	25322-31310	Gear, Cam Driven
8	25323-34201	Pawl, No.1
9	25324-34201	Pawl, No.2
10	09261-05003	Pin (5x8)
11	09440-04003	Spring
12	25331-38A00	Lifter, Pawl
13	25341-38A00	Guide, Cam
14	02122-0612A	Screw
15	09160-25059	Washer (25x32x3.0)
16	25332-24B01	Boss
17	08316-1006A	Nut
18	09262-25006	Bearing (25x47x8)
19	24741-21A00	Retainer, Bearing
20	02112-0612A	Screw
21	25350-24B00	Stopper, Cam
22	09448-17021	Spring
23	25356-12C00	Support
24	08211-06141	Washer
25	25380-38A02	Plate, Stopper
26	25312-38A00	Pin
27	25510-24B01	Shaft, Gear Shifting
28	09444-26013	Spring
29	25671-01011	Stopper, Arm
30	09285-12002	Oil Seal (12x22x9.0)
31	25600-24B03	Lever Assy, Gear Shifting
32	25652-20C00	• Rubber
33	25526-47000	• Cover, Dust
34	09160-12011	Washer (12.5x20x1)
35	08331-3112A	Circlip
36	25520-22A00	Arm, Gear Shift
37	25526-47000	• Cover, Dust
38	25525-21E50	Rod
39	09140-06025	Nut
40	08310-0006A	Nut
41	01500-0620A	Screw
42	08212-12201	Washer
43	08331-31126	Circlip
44	37720-24B30	Base Assy, Neut Switch Term
45	02112-7516A	Screw
46	09209-05011	Contact, Switch
47	09440-04010	Spring

Ref No	Part No	Description
1	31100-07F00	Motor Assy, Starting
2	31170-07F00	• . Frame Assy
3	31143-38300	• . O Ring
4	31132-45C00	• . Holder Set, Brush
5	31170-43400	• . Shim Set
6	31150-44B00	• . Bracket Set
7	31172-38300	• . Bush
8	31173-88C00	• . Bushing
9	08310-00067	• . Nut
10	08361-35068	• . Nut
11	31264-44110	• . O Ring
12	31281-24B10	• . Bolt
13	09280-35005	• . O Ring (d:2.1,id;34.7)
14	08361-35068	Nut
15	09103-06223	Bolt (6x20)




Ref No	Part No	Description
1	32101-24B02	Stator Assy
2	32102-24B10	Rotor
3	01547-06253	Bolt
4	01547-05103	Bolt
5	09103-14001	Bolt, Rotor (14x43)
6	09420-05007	Key
7	32371-24B00	Clamp, Lead Wire No.1
8	01547-05103	Bolt
9	31497-45000	Clamp, Lead Wire No.2
10	09100-05019	Bolt (5x10)







Ref No	Part No	Description
1	33610-05A10	Battery Assy (yb14l-b2)
2	33651-37000	Protector (170x95x3.0)
3	33651-37000	Protector (170x95x3.0)
4	33652-07D00	Protector (80x80x2.0)
5	33652-20C00	Protector (50x50x5.0)
6	33680-16A10	Hose, Battery Exhaust
7	09404-06429	Clamp, Hose (l:45)
8	33860-24B00	Lead Wire, Battery (-)
9	33870-24B00	Lead Wire, Battery (+)




Ref No	Part No	Description
1	31800-49100	Relay Assy, Starting Motor
2	01550-0610A	Bolt
3	08361-35068	Nut
4	33850-24B10	Wire, Starting Motor
5	33624-49401	Cap, Starter Relay
6	32800-24B10	Rectifier Assy
7	02162-06203	Screw
8	32900-24B30	Igniter Assy
9	32980-24B00	Cushion, Igniter
10	33410-24B00	Coil Assy, Ignition
11	02142-0512A	Screw
12	33510-45010	Cap, Spark Plug
13	33541-38210	Seal, Spark Plug
14	33542-38B00	Seal, High Tension Cord
15	32910-24B10	Control Unit, Decomp
16	33970-24B00	Solenoid Assy, Decomp
17	33971-24B00	Bracket, Decomp Solenoid
18	01550-0616A	Bolt
19	58900-24B01	Cable Assy, Decomp
20	09209-04020	Pin
21	08332-11033	E Ring




Ref No	Part No	Description
1	34110-24C20	Speedometer (mile/kilo)
2	34288-24B80	Cushion, Meter
3	34131-19B00	Box, Meter Gear
4	02112-04087	Screw
5	08321-01043	Lock Washer
6	34151-24B81	Hood, Meter
7	34111-24B80	Bracket, Meter
8	02112-04087	Screw
9	08321-01043	Lock Washer
10	34189-24B80	Cushion
11	34170-24B20	Socket, Meter
12	09471-12103	Bulb (12v,3w,t6.5)
13	09471-12108	Bulb (12v,1.7w,t6.5)
14	09440-11022	Spring
15	09160-05048	Washer (5.5x14x1.2)
16	08361-15053	Nut
17	34910-24B00	Cable Assy, Speedometer




Ref No	Part No	Description
1	34110-24B40	Speedometer (kilo)
2	34288-24B80	Cushion, Meter
3	34131-19B00	Box, Meter Gear
4	02112-04087	Screw
5	08321-01043	Lock Washer
6	34151-24B51	Hood, Meter
7	34111-24B80	Bracket, Meter
8	02112-04087	Screw
9	08321-01043	Lock Washer
10	34189-24B80	Cushion
11	34170-24B20	Socket, Meter
12	09471-12103	Bulb (12v,3w,t6.5)
13	09471-12108	Bulb (12v,1.7w,t6.5)
14	09440-11022	Spring
15	09160-05048	Washer (5.5x14x1.2)
16	08361-15053	Nut
17	34910-24B00	Cable Assy, Speedometer



Ref No	Part No	Description
1	35100-38A61-999	Headlamp Assy
2	35121-38A60	• . Unit, Lamp
3	35111-38A60	• . Rim
4	35130-38A00	• . Ring, Mounting
5	35173-13E10	• . Cover
6	35136-38A60	• . Screw
7	35136-38A00	• . Screw
8	35139-45230	• . Cushion
9	35139-38A60	• . Cushion
10	35155-38A60	• . Nut
11	09404-06432	• . Clamp (I:80)
12	35151-38A00	• . Screw, Adjust
13	35154-31300	• . Spring
14	35152-45600	• . Nut
15	36853-38A00	• . Socket
16	09471-12060	Bulb (12v,60/55w)
17	02142-05127	Screw, Head Lamp
18	35950-43431	Reflex Reflector, Front Side
19	08310-00053	Nut
20	08321-01053	Lock Washer
21	09160-05037	Washer
22	35956-24B00	Bracket, Front Side Rh
23	35957-24B00	Bracket, Front Side Lh
24	09136-05026	Screw




Ref No	Part No	Description
1	35601-38AD0	Lamp Assy, Front Turn, Rh
1	35602-38AD0	Lamp Assy, Front Turn, Lh
2	35610-38AA0	• . Lens
3	35630-38AA0	• . Lens
4	35623-38AA0	• . Screw (4x10)
5	09471-12083	• . Bulb (12v,21/8w)
6	02142-06107	Screw
7	35671-24B00	Bracket, Rh
8	35681-24B00	Bracket, Lh
9	01547-05257	Bolt
10	35603-38AA0	Lamp Assy, Rear Turn, Rh
10	35604-38AA0	Lamp Assy, Rear Turn, Lh
11	35630-38AE1	• . Lens
12	35610-38AE1	• . Lens
13	35623-38AA0	• . Screw (4x10)
14	09471-12045	• . Bulb (12v,21w)
15	02142-06167	Screw
16	09403-07315	Clamp, Lead Wire
17	38610-26E00	Relay, Turn Signal
18	38621-24B10	Bracket, Turn Signal Relay




Ref No	Part No	Description
1	35710-24B40	Lamp Assy, Rear Combination
2	35712-24B30	• Lens
3	35713-31D00	• Gasket
4	35714-38A00	• Reflector
5	35723-44130	• Screw
6	35627-43010	• Gasket
7	09471-12128	• Bulb (12v,21/5w)
8	35765-24B00	• Cushion
9	35764-26470	• Cushion
10	35766-40640	• Spacer
11	35766-24B40	• Spacer
12	09116-06093	Bolt
13	09308-09004	Grommet
14	35910-24B50	Lamp Assy, License
15	35917-17C10	• Cover, License Lamp
16	35912-38A30	• Lens
17	35913-38A30	• Gasket
18	35966-24B40	• Spacer
19	09471-12140	• Bulb (12v,5w)
20	08316-10043	Nut, License


FIG.27




Ref No	Part No	Description
1	36610-24BD0	Harness, Wiring
2	36611-38A00	• . Diode
3	09404-08207	Clamp (l:80)
4	09407-11401	Clamp (l:95)
4	09407-14403	Clamp (l:125)
4	09407-18402	Clamp (l:165)
4	09407-25401	Clamp (l:235)
5	36651-24B10	Clamp, Wiring Harness
5a	36920-08D10	Tape, Wiring Harness
6	36740-24B01	Fuse Assy, Main
7	09481-20101	• . Fuse (20a)
9a	37101-24830	Lock Set
9b	37101-24840	Lock Set
9c	37110-24B10	• . Switch Assy, Ignition
10	07130-0516A	Bolt
11	37740-45D00	Switch Assy, Stop Lamp
12	09443-06077	Spring
13	37840-12X50	Switch Assy, Side Stand
14	01550-0620A	Bolt
15	38740-24X50	Relay Assy.side Stand
16	38500-24B00	Horn Assy
17	02142-0612A	Screw
18	37146-03A00	Key, Blank Type C (a51)
18	37146-03A10	Key, Blank Type D (a52)
18	37146-03A20	Key, Blank Type E (a53)
18	37146-03A30	Key, Blank Type F (a54)
19	37146-38B00	Key, Blank "boulevard"
19	37146-38B10	Key, Blank "boulevard"
19	37146-38B20	Key, Blank "boulevard"
19	37146-38B30	Key, Blank "boulevard"




Ref No	Part No	Description
1	37200-24BF0	Switch Assy, Handle, R
2	02112-05167	• . Screw
3	37400-24BH0	Switch Assy, Handle, L
4	02112-05167	• . Screw



Ref No	Part No	Description
1	41100-24B01-019	Frame Set (black)
2	09409-06306	Cap, Frame Head
3	09106-08074	Bolt
4	41970-24B00-019	Plate, No.4 Rh (black)
5	41980-24B00-019	Plate, No.4 Lh (black)
6	41991-24B00-019	Plate, No.5 Rh (black)
7	41992-24B00-019	Plate, No.3 Lh (black)
8	09103-08279	Bolt
9	08319-21088	Nut
10	08321-01083	Lock Washer
11	08322-01083	Washer
12	41540-24B01	Holder, Battery
13	41576-24B01	Cover, Battery
14	02142-04107	Screw, Cover
15	09320-08021	Cushion
16	09180-06260	Spacer
17	09116-06010	Bolt





Ref No	Part No	Description
1	42310-24B01	Stand, Prop
2	42341-38B01	Bolt
3	09181-15158	Shim
4	43575-24B00	Cap
5	09140-10044	Nut
6	09443-15034	Spring, Inner
7	09443-18020	Spring, Outer
8	09103-10087	Bolt, No.1
9	43110-24B10	Pedal Assy, Brake
10	09448-32017	Spring
11	04111-30308	Cotter Pin
12	09100-06150	Bolt, Adjuster
13	08310-00063	Nut
14	09160-16043	Washer
15	58510-24B10	Cable
16	09209-13018	Pin
17	09150-06014	Nut
18	09200-05001	Pin
19	04111-20158	Cotter Pin
20	01570-06163	Bolt



Ref No	Part No	Description
1	43510-24B00	Bracket, Front Footrest Rh
2	43520-24B22	Bracket, Front Footrest Lh
3	43517-24B01	Holder, Front Footrest Rh
4	09140-16029	Nut, Rh
5	43530-24B02	Bar, Front Footrest Rh
6	43540-24B02	Bar, Front Footrest Lh
7	43551-38A00	Rubber
8	09106-06100	Bolt, Rubber
9	43576-24B00	Cap
10	43570-24B01	Cushion, Front Footrest
11	43470-24B00	Washer, Front Footrest Rh
12	43480-24B00	Washer, Front Footrest Lh
13	43600-24B00	Footrest Assy, Pillion Rh
14	43700-24B00	Footrest Assy, Pillion Lh
15	43610-24B01	• Bar, Pillion Footrest Rh
16	43710-24B01	• Bar, Pillion Footrest Lh
17	43651-24B00	• Rubber, Pillion Footrest
18	43621-24B10	• Holder, Pillion Footrest
19	09106-06100	• Bolt, Rubber
20	43570-38A00	• Washer, Rh
21	43580-38A00	• Washer, Lh
22	43576-24B00	• Cap, Bolt
23	43622-24B00	Washer, Holder
24	07130-10453	Bolt


Ref No	Part No	Description
1	44100-24C10-YAY	Tank Assy, Fuel (black)
1	44100-24C10-YC3	Tank Assy, Fuel (white)
1	44100-24C10-YBA	Tank Assy, Fuel (blue)
1	44100-24C20-YAY	Tank Assy, Fuel (black)
1	44100-24C20-YC3	Tank Assy, Fuel (white)
1	44100-24C20-YBA	Tank Assy, Fuel (blue)
2	68111-24C00	Emblem, Rh
3	68121-24C00	Emblem, Lh
4	44200-24830	Cap Set, Fuel Tank
4	44200-24820	Cap Set, Fuel Tank
5	09329-10016	Cushion, Front
6	44552-24B00	Molding, Rear
7	09320-10020	Cushion, Lower
8	09180-06271	Spacer
9	09320-14013	Cushion, Upper
10	01500-06303	Bolt








Ref No	Part No	Description
1	44911-43500	Hose, No.3
2	09364-04002	Joint
3	09401-08411	Clip
4	09401-06405	Clip
5	44240-38A00	Valve, Breather
6	09343-05403	Hose, No.1
7	09440-13041	Spring
8	09401-11413	Clip
9	44880-24B00	Plate, Fitting
10	44894-24A00	• . Cushion
11	44892-24A00	Plate, Valve
12	44894-24A00	• . Cushion
13	02142-04103	Screw
14	17210-24B00	Canister Assy
15	44911-43500	Hose, No.4
16	09401-06405	Clip
17	44991-24B00	Cover, Canister
18	09308-07004	Grommet
19	02142-06103	Screw
20	09116-06168	Bolt, Lower
21	09180-06260	Spacer
22	09320-08021	Cushion

Ref No	Part No	Description
1	44300-24B00	Cock Assy, Fuel
2	44348-28070	• . O Ring
3	09128-06006	Bolt
4	09168-06026	Gasket
5	09355-70125-600	Hose, Fuel (l:600->40)
6	09401-11407	Clip, Fuel Hose







Ref No	Part No	Description
1	47100-24CA0-YAY	Cover, Frame Rh (black)
1	47100-24CA0-YC3	Cover, Frame Rh (white)
1	47100-24CA0-YBA	Cover, Frame Rh (blue)
2	68131-24CA0	• . Emblem
3	13719-84150	• . Cushion
4	02142-05103	Screw
5	02112-75163	Screw, Lower
6	47200-24CA0-YAY	Cover, Frame Lh (black)
6	47200-24CA0-YC3	Cover, Frame Lh (white)
6	47200-24CA0-YBA	Cover, Frame Lh (blue)
7	68131-24CA0	• . Emblem
8	47180-24B03	Bracket, Frame Cover Lh
9	47117-45000	Cushion, Lh
10	02122-06123	Screw, Bracket
11	47430-24B01	Holder, Tool
12	47440-24B20	Cover, Tool Holder
13	33652-07D00	• . Protector
14	47445-24B00	• . Molding
15	02142-05103	Screw, Lower
16	02112-06103	Screw, Upper
17	95700-24870	Lock Assy, Tool Holder
18	47434-24B00	Plate, Lock
19	09800-21055	Tool Assy
20	96220-24B00	Gauge Assy, Tension




Ref No	Part No	Description
1	51810-38A03	Housing, Headlamp
2	08319-31063	Nut
3	53110-24B01-YAY	Fender, Front (black)
3	53110-24B01-YC3	Fender, Front (white)
3	53110-24B01-YBA	Fender, Front (blue)
4	01570-06163	Bolt




Ref No	Part No	Description
1	56110-24C00	Handlebar
2	56500-45C41	Mirror Assy, Rear View Rh
3	56600-45C41	Mirror Assy, Rear View Lh
4	58200-24C00	Cable Assy, Clutch
5	58300-24C00	Cable Assy, Throttle
6	02142-05087	Screw
7	58620-24B00	Clamp, Stop Lamp Switch
8	01570-06163	Bolt
9	58830-24B01	Cable, Stop Lamp Switch
10	09404-08206	Clamp, Stop Lamp Cable
11	09407-14407	Clamp, Rear Brake Cable
12	58621-24C00	Guide, Cable
13	09139-05033	Screw



Ref No	Part No	Description
1	57110-26D00	Grip, Throttle
2	57216-38A00	Cap
3	57420-24B01	Lever, Brake
4	57431-38A10	Bolt
5	08319-21068	Nut
6	57460-17C11	Switch Assy, Stop
7	57465-17C00	• . Screw
8	57210-26D00	Grip, Lh
9	57216-38A00	Cap
10	57500-24B01	Lever Assy, Clutch
11	57620-24B01	• . Lever, Clutch
12	57531-24B00	• . Bolt, Clutch Lever
13	57623-24B00	• . Spacer, Clutch Lever
14	08319-21068	• . Nut
15	57441-45C00	• . Adjuster, Wire
16	57442-45C00	• . Lock Nut
17	07130-06207	• . Bolt, Lever Holder
18	57560-05A00	• . Switch, Clutch
19	02112-03205	• . Screw
20	09407-25402	Band
21	57661-48E00	Cover, Clutch Lever




Ref No	Part No	Description
1	63100-24C00-YAY	Fender, Rear (black)
1	63100-24C00-YC3	Fender, Rear (white)
1	63100-24C00-YBA	Fender, Rear (white)
2	68271-34A00-YES	• . Emblem (silver)
2	68271-34A00-YJH	• . Emblem (gray)
3	09103-08152	Bolt
4	35916-24B01	Bracket, License Plate
5	09116-06010	Bolt
6	09180-06263	Spacer
7	09320-09016	Cushion
8	09404-06429	Clamp
9	95700-38821	Lock Set, Helmet
10	02112-05127	Screw




Ref No	Part No	Description
1	68319-29F00	Label, Warning
1	68319-29F10	Label, Warning (french)
2	68332-24B71	Label, Tire
2	68332-24B81	Label, Tire (french)
3	68387-24B10	Label, Hose Routing
4	68353-26E02	Label, Manual Notice
5	99011-24C62-03A	Manual, Owner's
5	99011-24C62-01A	Manual, Owner's (english)
5	99011-24C62-01F	Manual, Owner's (french)

FIG.41




Ref No	Part No	Description
1	45100-24BA0-HW9	Seat Assy
2	45149-24B00	. Cushion
3	45116-24B00	. Cushion, Center Front
4	45149-43500	. Cushion
5	45114-24B00	. Bracket, Seat Ctr
6	45118-24B00	. Cushion, Seat Ctr
7	09160-06066	. Washer
8	01550-06253	. Bolt
9	01550-06123	Bolt (6x12)
10	45119-24B00	Plate, Seat Front
11	45149-24BA0	Cushion, Seat Rear
12	09139-06115	Screw, Seat Sprt Rear


FIG.42




Ref No	Part No	Description
1	46240-24BA0	Handle, Pillion Rider Rh
2	46250-24BA0	Handle, Pillion Rider Lh
3	01550-08163	Bolt, Rear
4	01550-08453	Bolt, Front
5	08313-20087	Nut
6	09320-06016	Cushion



Ref No	Part No	Description
1	51103-24B50	Damper Assy, Front Fork Rh
2	51104-24B50	Damper Assy, Front Fork Lh
3	51130-24B50	. Tube, Outer Rh
4	51140-24B50	. Tube, Outer Lh
5	51173-20A00	. Dust Seal
6	51156-40301	. Ring, Stopper
7	51153-20A00	. Oil Seal
8	51158-14100	. Washer
9	51167-13A00	. Metal, Slide
10	51147-16510	. Bolt
11	51148-41310	. Gasket
12	07130-08407	. Bolt
13	51195-24B01	. Piece, Oil Lock
14	51146-24B01	. Cylinder
15	51177-49440	. Spring
16	51196-49440	. Ring, Piston
17	51120-24B01	. Tube, Inner
18	51121-14100	. Piston
19	51171-24B00	. Spring
20	51172-45C00	. Washer
21	51176-24B01	. Spacer
22	51117-40300	. O Ring
23	51351-24B00	. Cap
24	51201-01DA0	. Protector




Ref No	Part No	Description
1	51410-24B20	Stem, Steering
2	09265-30009	• Bearing (30x55x17)
3	51310-24B50	Stem Head, Steering
4	51357-24B00	• Washer
5	51353-24B10	Nut, Cap
6	51356-24B01	Washer
7	56211-24B50	Holder, Handle Upper
8	56221-24B50	Holder, Handle Lower
9	07130-08307	Bolt
10	56231-24B50	Arm
11	07130-10257	Bolt
12	09250-06009	Cap, Handle Clamp
13	56240-24B00	Cushion, Upper
14	56240-24B10	Cushion, Lower
15	09180-10065	Spacer
16	08319-31107	Nut
17	07130-10307	Bolt
18	51631-28000	Nut, Steering Stem
19	51643-49002	Dust Seal, Steering Upper
20	09265-25019	Bearing, Steering Upper (25x47x15)
21	51900-22662	Lock Assy, Steering (neiman)
22	68281-35F00	Emblem, "s"




Ref No	Part No	Description
1	54111-24B01	Hub, Front
2	08123-63027	Bearing
3	09180-15074	Spacer, Hub Bearing (15.3x21.7x56)
4	54711-24B01	Axle, Front
5	54740-24B00	Spacer, Axle Rh
6	54750-24B00	Spacer, Axle Lh
7	59211-24B10	Disc, Front Brake
8	09106-08049	Bolt (8x25.5)
9	55100-24B02	Tire, Front (100/90-19 57h) (irc)
10	55200-44610	Tube Assy, Wheel Inner
11	55261-15010	Protector, Inner Tube
12	55311-24B00	Rim, Wheel (wm2.15x19)
13	55320-24B10	Spoke Set, Front Wheel
14	55411-26G00	Balancer, Wheel No.2
14	55413-41F00	Balancer, Wheel No.3


FIG.46




Ref No	Part No	Description
1	59300-24B40-999	Caliper Assy, Lh
2	59300-24820	• . Piston Set
3	59300-24810	• • . Seal Set, Piston
4	59315-14600	• . Spring
5	59386-13A00	• . Boot
6	59382-27C30	• . Bolt
7	59303-14500	• . Boot
8	59305-14500	• . Bolt
9	59306-14500	• . Nut
10	59345-14600	• . Pin
11	59316-24B10	• . Retainer
12	59121-01A00	• . Bleeder
13	59122-01A00	• . Cap
14	59300-24850	Pad & Shim Set
15	59371-24B00	• . Shim
16	09104-10029	Bolt (10x38)
17	09162-10008	Washer
18	08322-01107	Washer



Ref No	Part No	Description
1	59600-38AA0	Cylinder Assy, Front Master
2	59600-04810	• . Piston/cup Set
3	59666-44300	•• .. Boot
4	59667-49460	• . Diaphragm
5	59669-10F00	• . Cap
6	02122-04127	• . Screw
7	59671-38A00	• . Holder
8	07130-06207	• . Bolt
9	59664-48B00	• . Protector
10	09250-05008	Cap
11	09360-10041	Bolt (10x1.00x22)
12	09161-10009	Washer
13	59480-24B40	Hose, Front Brake
14	59541-24B00	Guide, Brake Hose No.1
15	01547-06103	Bolt
16	59268-24B00	Guide, Brake Hose No.2



Ref No	Part No	Description
1	61100-24B03-019	Swinging Arm, Rear (black)
2	09263-22017	Bearing (22x29x30)
3	61282-24B01	Spacer, Center
4	61251-24B00	Spacer, Pivot
5	08211-14341	Thrust Washer
6	61262-45002	Dust Seal
7	61211-24B00	Shaft, Pivot
8	08319-31148	Nut
9	61222-38A01	Cap, Pivot
10	61310-24B02	Belt Case, Upper
11	61320-24B02	Belt Case, Lower
12	01550-06123	Bolt
13	02112-76123	Screw
14	62100-24B00	Absorber Assy, Rear Shock
15	62313-24B00	Bolt, Lower
16	09160-10035	Washer, Outer (10.5x28x2.3)
17	09160-14009	Washer, Upper Inner (14.5x29x2.3)
18	08313-10107	Nut



Ref No	Part No	Description
1	64110-24B00	Hub, Rear Wheel
2	09180-17069	Spacer (17.5x25x70)
3	08143-63037	Bearing
4	64651-31001	Shock Absorber, Hub
5	64210-24B01	Panel, Rear Brake Anchor
6	64400-44810	Shoe Set, Brake
7	55420-30000	Spring, Shoe
8	54440-08004	Cam, Rear Brake
9	09280-15003	O Ring (d:2.4,id:14.8)
10	09160-15048	Washer
11	64451-24B00	Lever, Brake Cam
12	09448-33006	Spring
13	01570-06253	Bolt
14	64611-31003	Drum, Sprocket
15	09262-25073	Bearing (25x62x17)
16	09285-33001	Oil Seal (33x62x7)
17	64733-31300	Retainer, Drum
18	09180-17082	Spacer, Rh (17.6x28x22.30)
19	09180-17083	Spacer, Lh (17x33x35.30)
20	64711-24B02	Axle, Rear
21	09160-17050	Washer
22	09159-16002	Nut
23	64510-24B02	Sprocket, Rear (nt:68)
24	01550-06123	• . Bolt
25	09105-10005	Bolt (10x40)
26	08319-31103	Nut
27	61410-24B01	Adjuster, Belt
28	09104-08027	Bolt (8x43)
29	08310-00087	Nut
30	65311-24B01	Rim, Rear Wheel (wm2.75x15 M/c)
31	65320-24B00	Spoke Set, Rear Wheel
32	65100-24B02	Tire, Rear (140/80-15 M/c 67h) (irc)
33	65200-26F10	Tube Assy, Wheel Inner
34	65261-26F00	Protector, Inner Tube
35	55411-26G00	Balancer, Wheel No.2
35	55413-41F00	Balancer, Wheel No.3

LS650K5 (LS650K5 E3/E28)

FIG50

OPTIONAL

Description

Ref No

Part No

Description

- 1
- 99000-25110
- 2
- 99104-32020
- 2
- 99104-32030
- 2
- 99000-32050
- 2
- 99000-32100
- 2
- 99000-32130
- 3
- 99000-32040
- 4
- 99000-31110
- 4
- 99000-31140
- 5
- 99000-25030
- 6
- 99000-25140

- Brake Pad Grease (pbc)
- Thread Lock, Super (1361a)
- Thread Lock, Super (1363a)
- Thread Lock, Super (1342)
- Thread Lock, Super (1305)
- Thread Lock, Super (1360)
- Thread Lock Cement
- Suzuki Bond (1215)
- Suzuki Bond (1207b)black
- Suzuki Super Grease
- Suzuki Moly Paste

